



Furrow Bottom Wear Plate

This furrow wear plate helps maintain furrow's profile ahead of the press wheel in multiple different soil conditions. This extension does not allow soil to immediately flow back into the void created.



First you will need to remove the two 7/16 bolts circled in yellow below. Loosed the other two as well and then remove the original front wear plate.(indicated by yellow arrow)



Use a torch or plasma cutter to remove the tab circled below. Then use a grinder to smooth the cut and make sure it is level with the bottom of the shoe. This can be done with the black cast iron wear plates still installed.



To install the new Furrow Bottom Wear Plate , bolt it loosely in place 7/16x2 bolts and locknuts. Make sure that it is even with the bottom of the shoe and will make a smooth furrow bottom. Remove more material with grinder if needed. Tighten locknuts when the fit is satisfactory.

Note* This wear plate will need to be removed when calibrating deflectors.

